

## Assembly of Product Sleeve EK 043



*Push Product Sleeve (or Splashguard EK 652) over the Scuffguard.*



*While pushing the Product Sleeve, turn it until it snaps in properly onto the Scuffguard.*



**Pay attention to the correct fit of the Product Sleeve:**

- 1) Correct position of the Scuffguard, the nozzle body has to be visible.*
- 2) The Product Sleeve has to snap into the Scuffguard: no gap between these two parts allowed.*
- 3) The parting line on the Product Sleeve has to be in line with the parting line of the Scuffguard.*